


Jabra Classic

How do I reset my Jabra Classic?

When you reset your Jabra Classic, the list of devices that have been paired with it is cleared. To reset your Jabra Classic, follow these steps:

1. Turn on your Jabra Classic.
2. Simultaneously press and hold the **Answer/end** button and the **Volume +** button for approximately 7 seconds.



3. Your Jabra Classic is now reset. Turn it off and then on, and it will go directly into pairing mode.

Note: When your Jabra Classic has been reset, you will need to re-pair it with your mobile phone. Remember to delete the previous pairing before you re-pair.