

Jabra Elite Sport (Original)

Why has my Jabra Elite Sport suddenly turned off?

The Jabra Elite Sport earbuds will automatically turn off to save battery in the following situations:

- The right earbud is out of range, or it has not been connected with your smartphone for at least 15 minutes.
To turn the earbuds back on, press the **Multi-function** button on the right earbud until the LED flashes.
- The right earbud has not been active for 1 hour.
To turn the earbuds back on, press the **Multi-function** button on the right earbud until the LED flashes.
- The left earbud has not been connected with the right earbud for 15 minutes.
To turn the earbuds back on, press the **Volume - (down)** button on the left earbud until the LED flashes. Alternatively, place both earbuds in the charging case and close the lid. After a few seconds, reopen the lid, and they will turn on again.