

Jabra Extreme 2

How do I manually turn off/on voice guidance on my Jabra Extreme2?

Prerequisites

- Firmware 5.4 or later

Voice guidance is turned on as the default setting, on your Jabra Extreme2.

To manually turn off/on voice guidance, follow these steps.

1. Start with the headset tuned off.
2. Press and hold (5 seconds) the **Answer/end** button and while holding the button down, turn the headset on. A short sound prompt will confirm the change.

