

# Jabra Speak 810 MS


## How do I turn off/on voice guidance on the speakerphone using Jabra Direct?

### Prerequisites

- Device firmware - latest version
- [Jabra Direct - latest version](#)

To turn off/on voice guidance using Jabra Direct, follow these steps.

1. In Jabra Direct, select your device.
2. Click **Device**.
3. In **Device settings** > **Speakerphone** > **Voice guidance**, click the slider to turn the setting off/on.



4. Click **Apply**.

### Note

Images and text are for guidance purposes only. Actual images and text

may vary depending on the connected device and updates to the software.

## Applicable products



**Jabra Connect 4s -  
USB-A**



**Jabra Speak 710 MS**



**Jabra Speak 710 UC**



**Jabra Speak 750 - UC**



**Jabra Speak 750 - MS  
Teams**



**Jabra Speak2 40 UC,  
Dark Grey**



**Jabra Speak2 40 MS  
Teams, Dark Grey**



**Jabra Speak2 55 UC  
Dark Grey**



**Jabra Speak2 55 MS  
Teams, Dark Grey**



**Jabra Speak 810 MS**



**Jabra Speak 810 UC**



**Jabra Speak 510**



**Jabra Speak 510 MS**



**Jabra Speak 510+**



**Jabra Speak 510+ MS**