


Jabra Sport Pulse Wireless

How do I reset my Jabra Sport Pulse Wireless?

When you reset your Jabra Sport Pulse Wireless, the list of devices that have been paired with it is cleared. Follow these steps to reset:

1. Turn on your Jabra Sport Pulse Wireless by pressing and holding the **Multi-function** button for at least 3 seconds, or until the indicator light flashes.
2. Simultaneously press and hold (5 seconds) the **Multi-function** button and the **Sports** button.



3. Your Jabra Sport Pulse Wireless is now reset, and it goes directly into pairing mode.
4. Turn on Bluetooth on your mobile phone, and select the Jabra Sport Pulse Wireless. Enter "0000" (4 zeros) if you are asked for a pin code.

Note: When your Jabra Sport Pulse Wireless has been reset, you will need to re-pair it with your mobile phone. Remember to delete the previous pairing before you re-pair.