

## Jabra Speak2 55 UC - Dark Grey

### How do I pair the Jabra Speak2 with my mobile device?

To pair the Jabra Speak2 with your smartphone, tablet, or other handheld mobile device, follow these steps.

1. Turn on the Bluetooth setting on your mobile device.
2. Press and hold (3 seconds) the **Bluetooth** button on the speakerphone.
3. Go to the Bluetooth menu on your mobile device and select the speakerphone from the list of available devices. If you are asked for a pin code, enter “0000” (four zeros).

The Bluetooth range is 10m/33ft.



#### Note

To disconnect or reconnect the speakerphone, tap the **Bluetooth** button.

## Applicable products



**Jabra Speak2 55 MS  
Teams - Dark Grey**



**Jabra Speak2 75 - UC -  
Link 380c, Dark Grey**



**Jabra Speak2 75 - UC -  
Link 380a, Dark Grey**



**Jabra Speak2 75 - MS  
Teams - Link 380c,**



**Jabra Speak2 55 UC -  
Dark Grey**



**Jabra Speak2 75 - MS  
Teams, Dark Grey**



**Jabra Speak2 75 - MS  
Teams - Link 380a,**



**Jabra Speak2 75 - UC,  
Dark Grey**