

Jabra Link 14201-10

How do I connect my Jabra GN9330e with Siemens Opti Point 410, 420, 500, 600?

Prerequisite:

Jabra GN9350 + Jabra LINK 14201-10 + Acoustic Adapter (only available from Siemens)

In combination with one of the following phones:

- Opti Point 410 standard / advance
- Opti Point 420 standard / advance
- Opti Point 500 basic / standard / advance
- Opti Point 600

+ Opti Point Acoustic Adapter:

- Minimum version number for: S30817-K7110-B508 -10
- Minimum version number for: S30817-K7110-N508 -1

+ HiPath phone system:

- HiPath 500 from V.5
- HiPath 1220 from V2.1 Build 032
- HiPath 2000 from V1.0
- HiPath 3000 from V3 SMR 14
- HiPath 3000 from V4 SMR 7
- HiPath 4000 from V1

Important: If any of the components are missing, remote call control will not work.

Connection:

Important: Note that remote call control for the Jabra GN9330e is only supported from version "L" or date code 9/09.

1. Plug the 1-sided end of the DHSG cable marked blue into the socket of the OptiPoint Acoustic Adapter marked with the "headset" symbol.
2. Insert the split end of the DHSG cable into the Jabra GN9330e base. Connect the RJ9 plug into the socket marked with a "phone" symbol and the RJ45 plug into the socket on the Jabra GN9330e marked "AUX".

**Software setup:**

Put the headset into the base and activate the "DHSG" mode.

Hold down the "phone" button on the base of the Jabra GN9330e for approximately 6 seconds until the online display (blue LED) on the headset starts to flash. The current software is displayed to you by activating the volume controller in the form of the charge display (green LED).

LEDs from left to right:


- LED 1 = RHL
- LED 2 = DHSG

- LED 3 = AEI
- LED 4 = MSH

You can subsequently switch to the different software modes (LED 1-4) using the volume controller on the headset. To confirm the software has successfully installed, the base automatically switches back to charge mode after approximately 15 seconds.

Base setup:

Set the phone setup switch (A-G) to "A".



Microphone level setup:

Make a call using the headset.

If the other party cannot hear you well or just faintly, activate the volume controller at the base until you can be understood clearly.

Phone setup:

Important: As soon as the headset is connected and set up, a reset must be performed on the OptiPoint for the EHS function to activate.

An optional headset button can be installed over the phone menu (combination: *91 > Select Button > Change Button > Headset > OK).

Headset answer/end:

As soon as the dial tone signal can be heard in the headset, you can answer the call by pressing the **Answer/end** button on the headset; end the call by pressing again.

