

Jabra GN9350e MS

How to connect my Jabra GN9350e with Alcatel Touch 4029, 4039

Prerequisite:

Jabra GN 9350 + Jabra LINK 14201-09

In combination with one of the following phones:

- IP Touch 4029
- IP Touch 4039


Connection:

2-sided end:

Insert the RJ45 plug into the socket marked "AUX" and the RJ9 plug into the base socket of the Jabra GN9350 marked with the "phone" symbol.


2-fold Y-coupling end:

Insert the 3.5 mm audio jack into the headset interface and the RJ12 plug into the bell socket of the phone. Now insert the phone's phone cable directly into the additional connector socket of the Y cable.




Software setup:

In the LCD display, set the Jabra GN9350 to "MSH" and press the OK button.




Base setup:

Set the phone setup switch to the "A" position.



Microphone level setup:

We recommend setting the microphone volume in the LCD display to 7 out of 12.



Headset answer/end:

As soon as the dial tone signal can be heard in the headset, you can answer the call by pressing the "answer/end" button on the headset; by pressing again the call is ended.



Phone setup:

For system software version 9.xx and higher:

No settings are required on the phone for the use of a headset. Following the correct adaptation of the audio jack, a headset symbol should appear in the "Phone display". If the headset symbol does not appear, please check the following settings:

Menu> Settings> Phone> Audio Jack> Select/ Activate Headset.

Phone setup with system software version below version 9.xx:

Important: The "Force Headset" function must not be activated on the phone, as otherwise it will not be possible to accept external calls!

Menu> Settings> Phone> Audio Jack> Force Headset OFF

Menu> Settings> Phone> Socket > Activate Headset

Dial tone signal transfer/ phone setup:

Important: The dial tone signal in the headset is only transmitted if one of the following ringtones is used, e.g., Standard / Classic / Cold River / Dooing-Dooing. > Menu> Settings> Dial Tone > Internal / External

Should the dial tone signal transfer not work even though you have set

up the correct ringtone, please check the following settings:

Menu > Settings > Phone > Internal/External, More Options

No sound, Progressive, Beeps> all points must be set to "OFF".

Calls being made via the headset can be connected / forwarded as follows:

Dial the phone number > "Forward" will now appear in the phone display

> now press on to the appropriate function key next to the phone display

> now you can end the call with the button marked "Handset".