

Jabra Elite 85h - Copper Black

When I manually change audio settings on my Jabra device, why does it not change in Jabra Sound+?

Prerequisites

- [Jabra Sound+ - Android](#)
- [Jabra Sound+ - iOS](#)

When a setting has been manually applied on your Jabra device, it overrides the current Moment in Jabra Sound+. A notification will appear to indicate that the Jabra device and Jabra Sound+ are not synchronized.

To re-synchronize Jabra Sound+ with your Jabra device, follow one of these steps.

1. Manually change the setting on your Jabra device to align with the selected Moment.
2. Change between Moments in Jabra Sound+. This will re-apply the Moment settings to your Jabra device and synchronize the devices.
3. Tap the notification. A pop-up will ask you to confirm the re-synchronization.

Note:

If you choose not to re-synchronize your Jabra device with Jabra Sound+, your device will continue to use the applied settings, although they will not be accurately displayed in Jabra Sound+.

Applicable products



**Jabra Elite 65t -
Copper Black**



**Jabra Elite 65t -
Titanium Black**



**Jabra Elite 65t - Gold
Beige**



Jabra Evolve 65e MS



Jabra Evolve 65e UC



Jabra Elite 85h - Navy



**Jabra Elite 85h -
Titanium Black**



**Jabra Elite 85h - Gold
Beige**



**Jabra Elite 85h -
Copper Black**



Jabra Elite 85h - Black



**Jabra Elite Active 65t
- Titanium Black**



**Jabra Elite Active 65t
- Copper Blue**



**Jabra Elite Active 65t
- Amazon Edition**



**Jabra Elite Active 65t
- Copper Red**



Jabra Evolve 65t MS



Jabra Evolve 65t UC